





USER MANUAL

UNI Dispensers 1, 2 & 3



Cleaning & Assembly



*Use mild dish soap and a soft nylon brush.
Keep food-contact parts (A1 & A2) in good condition.
Replace damaged or worn parts immediately to ensure food safety.

Any questions? Contact our customer service team: orders@reitzel.ch